

© ELECTROLUX HOME PRODUCTS
Customer Care - EMEA
Training and Operations Support
Technical Support

Publication
number

599 75 69-05

EN

Edition: 11/2013 - Rev. 01

**Condensation tumble
dryer
with heat pump**

INSPIRATION RANGE

BLUE FIRE

Disassembly instructions

INDEX

Contents

1	Safety and Installation	5
1.1	Safety measures	5
1.2	Setting up	6
2	Technical characteristics	7
3	Operating characteristics and construction	8
3.1	Principle of the heat pump	8
3.2	Low consumption mode	9
3.3	Construction characteristics	10
3.3.1	Drum	11
3.3.2	Air seal and drum rollers	11
3.3.3	Water circuit	12
3.3.4	Drum rotation principle	12
4	Electric components	13
4.1	Control board	13
4.2	Main circuit board ERD10	14
4.2.1	Main circuit board functions EDR10	15
4.3	Main circuit board EDR12	16
4.3.1	Main circuit board functions EDR12	17
4.4	Inverter motor control board. (only with EDR10 board)	18
4.5	Conductivity sensor	19
4.6	Tank filling pump	19
4.7	Level sensor	19
4.8	NTC probe	20
4.9	Drum light	20
4.10	Compressor	21
4.11	Thermal cut-out	21
4.12	Compressor motor capacitor	21
4.13	Compressor cooling fan	22
4.14	Door micro-switch	22
4.15	Motor	23
4.15.1	Asynchronous three-phase or Inverter motor technical details	23
5	Wiring diagram with EDR10	24
6	Wiring diagram with EDR12	25
7	Selector dial positions in diagnostics	26
8	Access to components	30
8.1	Upper fluff filter cleaning	30
8.2	Condenser filter cleaning	30
8.3	Clean condensation water filter	31
8.4	Worktop	31
8.5	Sides	32
8.6	Main electronic circuit board	33
8.7	Control panel	33
8.7.1	Control board	34
8.7.2	Board and Programme selector dial	34
8.7.3	Door	35
8.7.4	Plastic door handle, latch and hinge	35
8.7.5	Plastic door micro switch lever	36
8.7.6	Glass door handle, latch and hinge	37




8.7.7	Glass door micro-switch lever.....	37
8.8	Level sensor and condensation water pump.....	38
8.8.1	Level sensor.....	38
8.8.2	Condensation water pump.....	39
8.9	Inverter board and three-phase asynchronous motor.....	40
8.10	Rotating compressor running condenser.....	41
8.11	Temperature probe.....	42
8.12	Motor protector.....	42
8.13	Rear panel.....	43
8.14	Rear air seal.....	44
8.15	Anti-entanglement cone.....	44
8.16	Front panel.....	45
8.17	Drum light.....	45
8.18	Door micro-switch.....	46
8.19	Base board.....	46
8.20	Compressor cooling fan.....	47
8.21	Front air conduit.....	48
8.22	Front air seal.....	48
8.23	Heat exchanger compartment door.....	49
8.23.1	Heat exchanger compartment door seal.....	49
9	Alarms.....	50
9.1	Alarm display during normal operation.....	50
9.2	Reading the alarms.....	50
9.3	Cancelling the last alarm memorised.....	51
9.4	Notes about specific alarm codes.....	51
9.5	ALARMS TABLE.....	52
10	Troubleshooting.....	58
10.1	The diagnostics programme cannot be accessed.....	58
10.2	The LEDs do not light up after the buttons are pressed.....	59
10.3	The drying cycle is long and the washing is still humid.....	60
10.4	Checking the heat pump performance.....	61
10.4.1	Models without auxiliary condenser.....	61
10.4.2	Models with auxiliary condenser HP 2C.....	62
10.5	Servicing the heat pump circuit.....	63
10.5.1	Replace compressor.....	63
10.5.2	Filling.....	64
11	Door reversibility.....	65
12	Revisions.....	67

1 Safety and Installation

1.1 Safety measures




- Before starting work on an appliance, check that the earth in the lodgings is working properly by using an appropriate tool and follow the instructions described/illustrated on the Electrolux Learning Gateway portal
<http://electrolux.edvantage.net>
- This platform is not fitted with an ON/OFF switch. Before you access internal components, take the plug out of the socket to disconnect the power supply.
- When the servicing is completed, ensure that all the connections have been made properly and that all the appliance's safety conditions are as good as new.
- The connection between the earth terminal and the earthed metallic parts must have a low resistance.
- Servicing must be performed using a tool suitable for measuring the earthing connection in compliance with the IEC/EN 60335-1 standard and follow the instructions described/illustrated on the Electrolux Learning Gateway/Metratester portal
<http://electrolux.edvantage.net>
- The resistance reading taken during the trial should not exceed 0.1 Ohm.
- If the compressor needs to be replaced, check the earthing resistance between the earth contact and the accessible metallic part on the condenser.
- In the event of handling/replacing the electronic circuit board, use the ESD (Cod. 405 50 63-95/4) kit to avoid electrostatic discharges damaging the electronic circuit board, see S.B. No. 599 72 08-09.
- All the work to be performed inside the appliance requires specific skills and knowledge and may only be carried out by qualified and authorised service engineers.
- Some of the components in the mechanical part could cause injuries, so wear suitable protection and proceed with caution.
- If the compressor needs to be replaced, it must be welded and not connected via Lockring type connections.
- Always empty all the water from the condensation tank before laying the appliance on its side.
- If the appliance has to be placed on its side for maintenance or another reason, lie it on its left side, to avoid the risk of any residual water falling onto the main circuit board.
- When replacing components, please refer to the code shown in the list of spare parts relating to the appliance.



1.2 Setting up

Remove the external film. If necessary use a cutter blade




Take off the cardboard cover and remove the corner elements.

Remove the polystyrene base and set the tumble dryer in position.



The tumble dryer weighs approximately 60 kg



Adjust the four feet so that the appliance is installed perfectly level (using a spirit level), to allow for the correct flow of condensation water into the purpose-provided tank.





The feet must never be removed. A gap must always be left between the bottom of the tumble dryer and the floor to prevent the appliance from overheating.



2 Technical characteristics

Power supply voltage	230 V	
Power supply frequency	50 Hz	
Energy class	T IT	
Maximum power absorption	1,050 W	900 W
Maximum energy consumed per 1 hour cycle	1.6 KW/h	1.85 KW/h
Drum volume	118 litres	
Foot adjustment	+1.5 cm	
Weight	approx. 40 kg	
Operating temperature	+5°C/+35°C	
Triple-phase motor with permanent magnets	W 222	
Motor rotating speed	2,700 rpm	
Rotating compressor	480 W 220 V	
Coolant gas	R407C	
Amount of coolant gas	570g models without auxiliary condenser	650g models with auxiliary condenser
Drum speed	54 rpm	




3 Operating characteristics and construction

3.1 Principle of the heat pump

Operating principle

Operating principle with auxiliary condenser



The cycle of the tumble dryer heat pump consists in evaporating, compressing, condensing and expanding the refrigerant R 407c.

By pressing the START/PAUSE button the drying cycle begins, the gas in the circuit is conveyed by the compressor (6) to the condenser (2), where at the outlet the circulation pipe known as capillary (8) narrows. This capillary slows down the release of gas and ensures that the pressure inside the condenser (2) increases bringing the gas to a liquid status and a pressure level of around 27 bar.

This rise in pressure subsequently increases the temperature of the gas that is now liquid inside the condenser (2) reaching around 53°C.

The air circulated by the fan (7) passes through this condenser (2) overheating before entering the drum (3) where the washing is located.

The evaporator (1) is located at the capillary outlet (8) with the gas circulation pipe being larger than the capillary which thus expands the hot, liquid gas coming from the condenser (2).

This gas expansion means that the gas in its liquid state once again becomes a gaseous state causing the gas itself to cool and subsequently cooling the entire evaporator, bringing it to a temperature of around 20°C.

The, by now hot air is circulated by the fan (6) and passes through the washing in the drum (3) absorbing humidity and reaches the evaporator (1) humid and hot. The latter which is now at a lower temperature thanks to the expansion of the gas ensures that all the humidity in the circulating air condenses.

The condensed water created is collected in a tray (4) and conveyed via a pump to the tank (5) located above the drum.

At this point, the air is now cold and dry and goes through the condenser (2) again, once again overheating before entering the drum (3) and the gas now cooled in the evaporator (1) returns to the compressor where it will once again be compressed and sent into the condenser (2) re-starting the cycle.

The entire gas evaporating and compressing system is kept in balance by a NTC (9) located at the entrance to the capillary (8). This collaboration with the main circuit board ensures that if the outgoing temperature from the condenser surpasses a certain level a fan (10) located in front of the compressor starts working and lowers the temperature.

In the models with auxiliary condenser, the operating principle remains the same and the only single variant is in the auxiliary condenser positioned in series to the main condenser. This ensures that the whole system is better balanced, thus increasing performance.

3.2 Low consumption mode

In order to reduce electricity wastage when the cycle is not running, appliances in this platform offer two ways of enabling low consumption mode:

1. Stand-Off

When the appliance is switched off at the ON/OFF button, it is in the “Stand-Off” or “virtual” off status. The LEDs and the LCD screen are turned off and the buttons are disabled, although the main circuit board and certain electrical components are electrically powered.

You have to unplug the appliance fully to cut off the power supply.


2. Automatic turn off

Automatic turn off together with the Zero Watt circuit works as follows:

- By pressing the ON/OFF button to turn off the appliance, the supply voltage is cut off and the tumble dryer is secured (motor off, display off, etc...), the cycle and any options selected are reset, so that the next time the appliance is turned on, it is ready to perform a new programme.
- After 5 minutes, at the setting stage, no further instructions are given to the appliance and the programme and selected options are cancelled and the basic programme re-appears when turned on again.
- 5 minutes after the cycle ends, no command is sent to the appliance and all the settings are stored so that when the appliance is turned on again, the user can see if the cycle ended normally and if it should be started again.
- If an alarm goes off when a wash programme is running, the automatic off is disabled and an alarm is displayed.

These operations are carried out in order to save energy in compliance with the < 50 mW energy consumption standards.

3.3 Construction characteristics




- | | | |
|-----------------------------|--------------------------|---------------------------------------|
| 1. Front panel. | 11. Base (lower part). | 21. Pump compartment lid. |
| 2. Front air conduit. | 12. Condenser. | 22. Drum rollers. |
| 3. Drum. | 13. Evaporator. | 23. Fluff filter. |
| 4. Rear panel. | 14. Auxiliary condenser. | 24. Fluff filter base. |
| 5. Rear air conduit. | 15. Rotating compressor. | 25. Fluff filter access door. |
| 6. Sides. | 16. Compressor fan. | 26. Base board. |
| 7. Worktop. | 17. Motor. | 27. Door. |
| 8. Crossbars. | 18. Air circulation fan. | 28. Control panel with control board. |
| 9. Condensation water tank. | 19. Level sensor. | 29. Main board. |
| 10. Base (upper part). | 20. Pump. | 30. Motor control board. |

The front panel and sides are made of painted sheet metal, whereas the back panel is in zinc-coated sheet metal. These parts are fastened using self-tapping screws and are connected to the base.

The shaped base, in carboran, supports all the main elements.

3.3.1 Drum


The drum is made up of steel or zinc casing where inside there are three blades positioned at 120° one from the other which move the washing around during drum rotation.



3.3.2 Air seal and drum rollers


Front air seal

1. Drum.
2. Drum rotation roller.
3. Front air seal.
4. Front air conduit.




Rear air seal

5. Rear panel.
6. Rear air seal.
7. Drum.
8. Drum rotation roller.



3.3.3 Water circuit

- 1 Pump immersed in the trap.
- 2 Tank water drain pipe (red).
- 3 Water overflow drain pipe (transparent).
- 4 Tank support.
- 5 Level sensor.



The condensation water that forms inside the exchanger is collected in a trap.


There is a float (5) inside this trap that informs the circuit board that there is water. This powers a pump (1) which conveys the water through the red pipe (2) from the trap to the tank inserted in the tank support (4).

The tank was designed to receive the condensation water of a complete cycle at full load, approximately 5.5 litres.

If, for whatever reason, the tank fills up beyond its capacity, the overflowing water is collected by the support tank and via the transparent pipe (3), is re-conveyed inside the trap pushing the float (5) upwards and this activates the micro switch. The electronic makes 7 attempts to empty the trap within a set time, after which the electronic control recognises the problem and disconnects the power supply to the appliance and lights up a LED informing the user that the tank is full.

3.3.4 Drum rotation principle

- 1 Motor.
- 2 Inverter motor board support.
- 3 Belt tensioner spring.
- 4 Belt tensioner.
- 5 Belt.



The drum is turned by a belt (5) which is driven by a motor pulley (1) fixed to the base.

There is a belt tensioner (4) on the motor casing, which increases the angle at which the belt winds onto the drum and works in a pair with the belt tensioner spring (3).

Two-way rotation of the drum is determined by the circuit board, which reverses the direction of power supplied to the motor briefly. The drum rotating in the opposite direction allows the laundry to untangle.


4 Electric components

4.1 Control board

The control board or control panel is designed to allow the setting of the various programmes via the selector and to select the various options by pressing specific keys.

Depending on the appliance model, the control board can be fitted with an LCD to display the various options selected, along with the drying phases, any alarms, the time left until the end of the cycle and other information.


- A Main circuit board.
- B Control board.
- C LCD.
- D Selector dial (not on the TC1 model).




TC1




TC2



TC3




TC4




4.2 Main circuit board ERD10

- A Main circuit board.
- B Sensors.
- C Inverter motor board.
- D Actuators.
- E Control board.
- F LCD (only on certain models).
- G Selector.




The electronic control unit is made up of a circuit board inserted in a plastic box, secured onto the top right crossbar.

This board receives information from the various sensors located on the tumble dryer and from the control board and elaborates the data and in turn controls all the actuators.



4.2.1 Main circuit board functions EDR10


- Acquires the commands for the drying cycle set-up.
- Powers up all the main components: Pump, drum rotation motor, heater unit and drum light.
- Controls the temperature of the air inside the tumble dryer (by means of an NTC probe), the humidity level in the washing (by means of the conductivity sensor), the level of the tank and the door safety lock.



- | | |
|----------------------------------|------------------------------|
| 1. Compressor cooling fan. | 6. Drum light. |
| 2. Inverter motor control board. | 7. Door safety micro switch. |
| 3. Condensation water pump. | 8. Compressor |
| 4. Temperature probe. | 9. Control board. |
| 5. Level sensor. | 10. Humidity sensor. |


4.3 Main circuit board EDR12

- A Main circuit board.
- B Sensors.
- C Inverter motor.
- D Actuators.
- E Control board.
- F LCD (only on certain models).
- G Selector.




The electronic control unit is made up of a circuit board inserted in a plastic box, secured onto the top right crossbar.

This board receives information from the various sensors located on the tumble dryer and from the control board and elaborates the data and in turn controls all the actuators.



4.3.1 Main circuit board functions EDR12


- Acquires the commands for the drying cycle set-up.
- Powers up all the main components: Pump, drum rotation motor, heater unit and drum light.
- Controls the temperature of the air inside the tumble dryer (by means of an NTC probe), the humidity level in the washing (by means of the conductivity sensor), the level of the tank and the door safety lock.



- | | |
|------------------------------|-----------------------|
| 1. Drum rotation motor. | 6. Drum light. |
| 2. Compressor. | 7. Level sensor. |
| 3. Compressor cooling fan. | 8. Temperature probe. |
| 4. Condensation water pump. | 9. Control board. |
| 5. Door safety micro switch. | 10. Humidity sensor. |


4.4 Inverter motor control board. (only with EDR10 board)

- T IT Inverter motor control board.
- B Inverter motor.
- E Main electronic circuit board.




The Inverter motor control board receives the clock pulses and power from the main circuit board. It controls the drum rotation motor.

In the event of a fault, the motor is protected by the circuit board which detects greater current absorption and cuts off the power supply to the motor.



Operating principle of the Inverter motor control board

- L Phase.
- N Neutral.
- A Inverter motor control board.
- B Motor.
- C Condenser.
- D Diodes.
- I1-I6 Switches.
- F1-F3 Motor connectors.
- μP Microprocessor.



To transform the single-phase electricity (available in our homes) into three-phase electricity, a new circuit board is used (A) to transform the energy from single-phase to three-phase, which can be modulated in breadth and frequency respectively to adjust the power and number of revolutions of the motor.


Single-phase electricity (applied to connectors L-N) is rectified by the diode jumper (D), so there is a direct voltage of 310 V at the ends of capacitor C, which through the combination of the opening and closing of switches I1⇒I6 (piloted by the processor) determines the piloting voltage and frequency of the motor.

4.5 Conductivity sensor

These electronics use a conductivity sensor, comprising an electronic circuit (located inside the main circuit board) and a part outside the board comprising two sensors positioned on the front air conduit.

When the drum is empty, there is an infinite impedance between the two sensors, while its value is affected by the washing load, by the type of fabric and by the degree of humidity in the washing placed inside the drum.

The main circuit board continuously receives information about the condition of the laundry inside the drum via the conductivity sensor, receives the settings made by the operator at the start of the cycle via the control board and processes these values in order to determine the amount of time left until the end of the cycle.



4.6 Tank filling pump

The pump is activated by a synchronous motor and is used to pump condensation water from the tray to the tank.

The pump is powered by a TRIAC on the main board.

Insulation class	155
Motor type	Asynchronous
Volt (V AC)	220-240
Frequency (Hz)	50 Hz
Power (W)	5 W
Resistor at 20°C	764 $\Omega \pm 10\%$



4.7 Level sensor

The condensation water level sensor is fitted on the rear of the tumble dryer and beside the tank filling pump.


It consists of a float with a magnet at the top and a reed switch positioned on the float guide/support.

When the water forming on the heat exchanger (condenser) falls into the collection tray this causes the float to rise up subsequently bringing the magnet closer to the reed switch which sends a signal to the main circuit board activating the tank loading pump.



4.8 NTC probe

This sensor is fixed to the hot air fan screw. It comprises a heating element, inserted in a metal capsule, with a value that decreases as the temperature rises. The electronic circuit reads the value of the heating element (which depends on the temperature inside the tumble dryer) and when it drops below a certain value, cuts the power supply to the heater unit. As the air cools, the value of the heating element increases, and when it reaches a certain value the electronic circuit restores the power supply to the heater unit. This occurs every time the temperature inside the appliance exceeds a given value, which varies according to the drying cycle that has been selected.




- 1 Terminals.
- 2 NTC heating element.
- 3 Metal capsule.
- 4 Plastic casing.

Temperature (°C)	Heating element Ω		
	Rated value	Maximum Value	Minimum value
20	6,050 - 5,617	6,335 - 5,686	5,765 - 5,548
60	1,393 - 1,250	1,419 - 1,222	1,367 - 1,278
80	725 - 640	743 - 620	707 - 660


4.9 Drum light

The drum light consists of a high luminosity LED diode inserted in a plastic support and fitted onto the front air conduit.

The lamp is powered directly by the main circuit board when the door is opened with a voltage of 5 V.



R1	3.3 Ω
R2	3.3 Ω
Current	150 mA
Power	3.3 V




4.10 Compressor

The compressor activates the coolant fluid circuit (R407c).

Power supply voltage	220 V 50 Hz
Power consumed	480 Watt
Main coil resistance	$6.84 \Omega \pm 7\%$
Auxiliary coil resistance	$5.88 \Omega \pm 5\%$
Overall weight	8.5 kg
Oil	210 cm ³ +10 cm ³ NMOC Ze – Gles RB68EP




- A Line.
- B Heat protection.
- C Run capacitor.
- D Auxiliary coil.
- E Primary coil.



4.11 Thermal cut-out

The heat protection is formed by a bimetallic which intervenes when the motor - due to excess effort - increases current absorption and consequently rises in temperature.



4.12 Compressor motor capacitor

The condenser enhances the performance of the compressor motor.

18 μ F 400 V



4.13 Compressor cooling fan

Axial fan on ball bearings

Power supply voltage	132-240 V
	50-60 Hz
Power consumed	23 W
Rotating speed rpm	2,600/3,000
Air flow at 2,600 rpm	2.32 m ³
Air flow at 3000 rpm	2.72 m ³



4.14 Door micro-switch


The door switch makes it possible for the electric components to be powered after the door has been closed. The switch is located above the door and it is closed, when the door itself is closed, by means of a pin located on the door itself.



4.15 Motor


The asynchronous three-phase motor used in this tumble dryer has permanent magnets and is driver directly by the inverter motor control board, which in turn receives commands from the main circuit board.

- 1 Fan.
- 2 Belt tensioner.
- 3 Motor.
- 4 Vibration damping bushes.




The motor unit consists of a belt tensioner (2) situated on an axis on the motor casing and secured by a spring ring, with one fan (1) for the circulation of hot air, bolted to the motor shaft, of the motor (3) with thermal cut-out and two vibration damping bushes (4) positioned on the two motor casings. The motor power connector is located on a shaft fixed to a casing.

Calmed




4.15.1 Asynchronous three-phase or Inverter motor technical details

Power supply voltage	230 V
Frequency	50 Hz
RPM	2,700
Coil resistance 1 - 2	20.4 Ω \pm 7% at 20°C
Coil resistance 1 - 3	20.4 Ω \pm 7% at 20°C
Coil resistance 2 - 3	20.4 Ω \pm 7% at 20°C




5 Wiring diagram with EDR10



1. Main board.
2. Anti-disturbance filter.
3. Water collection tray micro switch.
4. Filter sensor.
5. Temperature probe.
6. Humidity sensor.
7. User interface card.
8. Drum rotation motor.
9. Inverter board (motor piloting).
10. Inverter board.
11. Compressor fan.
12. Condensation water pump.
13. Compressor.
14. Drum light.
15. Door safety micro switch.
- X. Not used in series 6 and 7.

6 Wiring diagram with EDR12



- | | |
|--|-------------------------------------|
| 1. Main board. | 7. Compressor. |
| 2. Anti-disturbance filter. | 8. Compressor fan. |
| 3. Temperature probe. | 9. Condensation water pump. |
| 4. Water collection tray micro switch. | 10. Compressor drum rotation motor. |
| 5. Humidity sensor. | 11. Drum light. |
| 6. User interface card. | 12. Door safety micro switch. |

7 Selector dial positions in diagnostics




The alarms are enabled during diagnostic testing of components. If an alarm appears, move the selector to the first position to exit the alarm status and, if necessary, continue the test (if the alarm is not triggered again).


To check the correct functioning of the float switch and pump, the trap should be filled with approximately 0.7 litres of water.

In order to test the conductivity sensor properly in case of a short-circuit (position 8), a short circuit must be created between the two sensors on the front air conduit before moving the selector dial to the eighth position. If the short-circuit is not created properly, the circuit board will display alarm E32 (sensor frequency too low). To exit this alarm, move the selector to the first position.

In the TC1 models with no selector press touchkey **A** to move on to the next test or press pushbutton **B** to return to the previous test.



Position 1

User interface test	Purpose of the test:	To test the functionality of all LEDs and switches
	Components activated:	All LEDs. LCD display.
	Behaviour:	All LEDs flash in sequence. Press a button and the corresponding LED is lit; the code is shown on the LCD display and the buzzer sounds. All LCD icons flash simultaneously
	Working conditions:	There is a control to run the test (always active).

Position 2

Float micro-switch and condensation water pump



Purpose of the test:	To test the pump and micro-switch situated in the condensation water tray.
Components activated:	If the condensation water collection tray is full and the micro-switch detects this condition, the pump is started.
Behaviour:	If the water level in the tray is low, the LCD displays III and if the level is high (micro-switch triggered), the LCD displays 000.
Working conditions:	Door closed (time out 10 secs).

Position 3

Counter Clockwise drum rotation



Purpose of the test:	To test the drum rotation motor in an anti-clockwise direction.
Components activated:	Motor TRIAC. Anti-clockwise direction relay. Drum rotation motor. Condensation water filling pump.
Behaviour:	The motor turns the drum anti-clockwise and the condensation water filling pump is in operation.
Working conditions:	Door closed (time out 10 mins).

Position 4

Compressor cooling fan



Purpose of the test:	Test operation of the compressor cooling fan.
Components activated:	Compressor cooling fan TRIAC. Safety relay.
Behaviour:	LCD indicates the position of the selector.
Working conditions:	Door closed (time out 10 mins).

Position 5

Clockwise drum rotation



Purpose of the test:	To test clockwise rotation of the drum.
Components activated:	Clockwise drum rotation motor. Safety relay.
Behaviour:	LCD indicates the position of the selector. the drying temperature NTC1 is displayed on the LCD.
Working conditions:	Door closed (time out 10 secs).

Position 6

Compressor and clockwise drum rotation



Purpose of the test:

To test compressor operation.

Components activated:

Compressor.
Clockwise drum rotation motor.

Behaviour:

LCD indicates the position of the selector.
the drying temperature NTC1 is displayed on the LCD.

Working conditions:

Door closed (time out 10 secs).

Position 7

Open-circuited conductivity sensor



Purpose of the test:

To check the conductivity sensor in open-circuit conditions.

Components activated:

Conductivity sensor.

Behaviour:

The test lasts 4 seconds, during which the LCD flashes, displaying 000.
At the end of the test, the LCD stops flashing and displays III.
If the test was unsuccessful, the LCD continues to flash, displaying.

Working conditions:

Conductivity sensor free from any garments or contact.

Position 8

Closed circuited conductivity sensor



Purpose of the test:

To verify conductivity sensor in short circuit condition.

Components activated:

Conductivity sensor.

Behaviour:

The test lasts 4 seconds, during which the LCD flashes, displaying 000.
At the end of the test, the LCD stops flashing and displays III.
If the test is unsuccessful, the LCD displays the alarm E32.

Working conditions:

Short-circuited conductivity sensor.



Create a short circuit between the two sensors on the front air conduit before setting the selector dial to the eighth position.

Position 9

Condenser Tank Switch



Purpose of the test:

To test the micro-switch under the condensation water collection tray.

Components activated:

If the condensation water collection tray is full and the micro-switch detects this condition, the pump is started.


Behaviour:

If the water level in the tray is low, the LCD displays III and if the level is high (micro-switch triggered), the LCD displays 000.

Working conditions:

Door closed (time out 10 secs).

Position 10

Last alarm display and possible reset	Purpose of the test:	To see the alarm and delete it.
	Behaviour:	The LCD display flashes and shows any alarm present.
	Working conditions:	Turn the dial to position 10, paying attention not to stop in position 8 in order to avoid error 32. Press the START/PAUSE button to see all the alarms present. To delete the alarms, hold down the START/ PAUSE buttons and press the button on the left.

Position 11 and subsequent positions

	Behaviour:	All LEDs flash in sequence. Press a button and the corresponding LED is lit; the code is shown on the LCD display and the buzzer sounds.
	Working conditions:	Door closed (time out 10 secs).

8 Access to components

8.1 Upper fluff filter cleaning

- Open the door.
- Remove the fluff filter by pulling it upwards.
- Open it and remove all fluff.
- Any residual fluff should be removed by washing the filter under running water.




8.2 Condenser filter cleaning

- Open the door.
- Move the locking lever towards the right.
- Open the door in the kick plate.
- Rotate the locking lever clockwise and open the door.





- Pull the filter outwards to remove it.
- Clean it and if necessary wash under running water taking care not to damage it.



8.3 Clean condensation water filter

- Remove the condenser filter.
- Lift the condensation water filter up slightly.
- Remove and wash it.




8.4 Worktop

- Loosen the 2 rear fixing screws.




- Remove the tank.
- Loosen the front fixing screw.
- Move the worktop towards the rear and remove it.



8.5 Sides


- Remove the worktop.
- Loosen the screws that secure the sides to the top crossbars.



- Unscrew the 4 screws for each side located at the back of the tumble dryer.




- Raise the panel slightly so that the catch on the tumble dryer is released from the pocket in the panel.




8.6 Main electronic circuit board

- Remove the worktop.
- Remove the right side panel.
- Release the fixing clips from the board guard and remove it by pulling it up.




- Disconnect all connectors, making a note of their positions.
- Remove the two fastening screws from the crossbar.
- Move the entire board assembly towards the control panel so as to unhook and remove it.




8.7 Control panel


- Remove the worktop.
- Remove the tank.
- Loosen the three screws securing the control panel to the uprights and air conduit.



- Loosen the 2 screws that secure the control panel to the tank support.




- Turn it forward.
- Remove the wiring, making a note of the position of the various connectors.
- Remove the entire control panel.




8.7.1 Control board

- Using a screwdriver, release the fixing clips and concurrently raise the entire board assembly until it is fully removed.



8.7.2 Board and Programme selector dial

- To remove the selector board and respective dial, loosen the two screws that secure the board to the control panel (do not loosen the central screw).
 - Move the clips that secure it in place and raise it.
- In addition to the board, the selector dial will also be removed: to remove the dial, simply slip it off the pin.



8.7.3 Door

To remove the dryer door, irrespective of whether it is a plastic dummy door or in transparent glass, proceed as follows:

- Loosen the 2 screws securing the appliance door to the front panel.
- Lift up slightly so that the hook unhooks and remove it.



Caution: the glass door weighs approximately 4.5 kg




8.7.4 Plastic door handle, latch and hinge

- Unscrew the 8 screws all around the door and remove the internal cover.
- Using a screwdriver, and taking care not to damage the frame, remove the door crosspiece.




- Loosen the 2 screws securing the hinge and remove it.
- Pull out the pin securing the hinge and latch and remove them.



8.7.5 Plastic door micro switch lever

- Insert the door micro-switch lever so that the reference pocket is positioned towards the inside the inner frame and it coincides with the notch in the outer frame.




8.7.6 Glass door handle, latch and hinge

- Unscrew the 4 perimetral screws that attach the hinge unit to the door.
- Using a screwdriver and taking care not to damage the frame, remove the whole hinge unit.




- Unscrew the remaining 8 screws that hold the frame to the door and remove it.
- Loosen the two screws securing the handle assembly and remove it by pushing it out.



8.7.7 Glass door micro-switch lever

- To remove the door micro-switch lever, press the fastening clip.
- Push the lever in the direction shown by the arrow until you have removed it completely.
- Insert the lever as far as it can go to re-assemble it so that the fastening clips block it.




8.8 Level sensor and condensation water pump

- Loosen the screws that hold on the level sensor compartment lid and pump.
- Unhook the fastening clip.
- Remove the protection.




8.8.1 Level sensor

- Detach the connector and remove it.
- Move the retaining hooks indicated by the arrows slightly and remove the level sensor by pulling it up.




8.8.2 Condensation water pump


- Using pliers, loosen and raise the clamp securing the red pipe (supply) and raise it a few centimetres.
- Repeat the operation with the transparent pipe (overflow return).



- Disconnect the 2 pump connectors and the level sensor connector.
- Loosen the screw that holds the whole pump and level sensor to the machine and remove it.



- Insert a screwdriver in the slots indicated by the arrows and remove the pump by pushing it down.




8.9 Inverter board and three-phase asynchronous motor


- Remove the worktop.
- Remove the right side panel.
- Loosen the 2 screws securing the Inverter motor control board and remove it by raising it slightly and pulling it outwards.




- Loosen the 10 screws that hold the rear air conduit.
- If necessary, use a screwdriver to unhook the clips that hold it and remove it.




- Loosen the bolt that holds the hot air circulation fan.
- Remove it by pulling it outwards.



- Loosen the 2 screws that hold the inverter motor board support rod.
- Pull it upwards and remove it.



- Disconnect the motor connector.
- Using pliers, release the spring keeping the belt tensioner in tension.
- Remove the belt from the tensioner belt and motor axis.
- Loosen the screws that hold the front and rear motor fastening rods, lift them up by rotating them and remove them by pulling them off the rear hook.



- Slightly rotate the whole motor unit.
- Lift it up and remove.



8.10 Rotating compressor running condenser

- Remove the worktop.
- Remove the right side panel.
- Remove the drum rotating motor.
- Disconnect the 2 connectors.
- Loosen the screws that hold the condenser in its slot and remove it by pulling it upwards.




8.11 Temperature probe

- Remove the worktop.
- Remove the right side panel.


We recommend you remove the drum rotation motor to make this operation easier.

- Disconnect the probe.
- Remove the probe holding metallic clip (2).
- Pull the probe (1) upwards in order to remove it from its slot.



8.12 Motor protector

- To reach the thermal motor protection, loosen the screw indicated by the arrow which secures the protective cap.




The thermal motor protection is located inside it (indicated by the arrow), kept in contact with the motor by a spring and the motor contacts.




WARNING

Before disconnecting the electrical wires, make a note of their position.



8.13 Rear panel

- Remove the worktop.
- Remove the sides.
- Using pliers, open the clamp and disconnect the red pipe from the fitting.
- Pull out the red pipe so it is free from the rear panel.
- Loosen the screws securing the tank fitting and remove it.




- Disconnect the power supply cable from the main board.
- Disconnect all the mass connections on the back panel.



Warning to remove the connectors slightly lower the locking lever indicated in the figure.



- Remove the rear air conduit.
- Loosen the 2 screws securing the rear panel to the appliance base.
- Loosen the 4 screws securing the rear panel to the side crossbars and the screw securing it to the central crossbar.
- Release the clip on the tank support.
- Tilt and remove the back panel.




8.14 Rear air seal

- Remove the rear panel.
- Raise the air seal to remove it completely.





When repositioning the air seal, make sure the joint is positioned more or less under the tank support as shown in the figure.



8.15 Anti-entanglement cone


The anti-entanglement cone ensures that during the drying stage the washing does not get tangled up in itself.

- Press the blocking pin to remove and rotate the cone anti-clockwise.
- Loosen the three fastening screws to also remove the base.
- Insert the cone in its slot to re-assemble it and rotate it clockwise until you hear a click that indicates the correct insertion of the blocking pin.




8.16 Front panel

- Remove the worktop.
- Remove the control panel (you do not need to disconnect it electrically).
- Loosen the 2 screws securing the appliance door to the air conduit.
- Remove, where featured, using a screwdriver, the styling cover situated above the door interlock (not shown in the figure).
- Loosen the 3 screws securing the front panel to the air conduit.




- Loosen the 2 screws on either side securing the front panel to the air conduit.
- Tilt the front panel slightly forward and lift it.




8.17 Drum light

- Remove the frontal piece.
- Disconnect the connector.
- Press the two clips securing the drum light slightly and concurrently push it in until it is fully removed.




8.18 Door micro-switch

- Remove the frontal piece.
- Disconnect the connector.
- Pull out the entire assembly.




8.19 Base board

- Loosen the 2 front screws.
- Loosen the rear screw on the right side.




- Using a pair of pliers, unhook the holding clips on the left and right.
- When re-assembling, firstly insert the 3 lower blocking hooks.




8.20 Compressor cooling fan

- Remove the worktop.
- Remove the side panels.
- Remove the support.
- Disconnect and pull out the cabling.




- Loosen the 2 screws that hold the fan in the lower part.
- Lift up the 2 upper holding hooks and simultaneously remove the fan.



8.21 Front air conduit

- Remove the frontal piece.
- Loosen the 13 screws securing the front air conduit to the crossbars, to the tank support and to the appliance base.
- Raise the two crossbars slightly so as to remove them.
- Tilt the entire air conduit forward and lift it off.



8.22 Front air seal

Once the front air conduit has been removed, the air seal can be removed.

- Raise the air seal to remove it completely.
-
- When repositioning the front air seal, make sure the joint is positioned as shown in the figure.




8.23 Heat exchanger compartment door

- Open the kick plate door.
- Open the heat exchanger compartment door completely.
- Turn it slightly so that the hinge pins are fully released from their seats.
- To reposition the door, position the pins on the hinges.
- Press down fully so that the hinge pins click back into their seats.



8.23.1 Heat exchanger compartment door seal

- Open the kick plate door.
- Open the heat exchanger compartment door completely. You do not need to remove it.
- Raise the seal and remove it.



9 Alarms

Operation of the alarms is configurable according to the model. Some or all of the alarms may be displayed to the user.

When an alarm condition occurs, the drying cycle may be interrupted or paused; in some cases, for safety reasons, a forced cooling cycle is performed.

In this case, the electronic board, if possible, disconnects the power relay from the heating element and powers the drum rotation motor with cooling fan. The cycle remains active until the user switches off the appliance.

9.1 Alarm display during normal operation

On models with LCD the system displays the family of the current alarm to the user.

- First digit: letter “E”.
- Second digit: the family of the alarm.
- Third digit: the alarm number.

If we consider, for example, the alarm E53 (communication error between the motor control board and the main board), the following will be displayed:

- First digit: letter “E” (error).
- Second-third digit: the number “5 0”, i.e. the family of the alarm E53.

9.2 Reading the alarms

To read the last alarm code stored, proceed as follows:

- ⇒ Access diagnostics mode (see paragraph).
- ⇒ Turn the programme selector dial clockwise to the tenth position and the display will show the last code stored.
- ⇒ To display any other alarms, press the START/PAUSE button.



*Try not to stop on position 8, otherwise a dummy alarm is triggered!
Alarm 32*

- First digit: letter “E”.
- Second digit: the family of the alarm.
- Third digit: the alarm number.

The configuration errors E93 are displayed through the flashing of all LEDs and it is not possible to access the diagnostics system.

9.3 Cancelling the last alarm memorised

It is good practice to cancel the alarm code from the memory:

- After reading the alarm, to check whether it is repeated during the diagnostics cycle.
 - After effecting repairs to the appliance, to check whether it is repeated during testing.
1. Start diagnostics mode.
 2. Turn the programme selector in a clockwise direction to position ten.
 3. Press the Start/Pause button and the button immediately to the left of it simultaneously.
 4. Hold the buttons down for approximately 5 seconds.
 5. After deleting, E00 will be displayed.

9.4 Notes about specific alarm codes

- **Configuration alarm E93:**

When configuration alarms are displayed (when the appliance is switched on), the appliance is inoperative and all the LEDs light. It is not possible to access diagnostics; the only operation possible is to switch off the appliance (selector knob on position "0").

- **Alarms EH1-EH2-EH3:**

In the event of problems with the power supply, the appliance remains in alarm mode until the voltage and frequency are restored to within the normal limits or the appliance is switched off. Alarm family "H" is displayed and it is not possible to access diagnostic mode nor to use the "rapid alarm display" function.

The complete alarm can be read only when the abnormal condition has terminated.

9.5 ALARMS TABLE

FAMILY		ALARM CODE	Full name	Action	Notes and possible causes
Ex20	CONDENSATION WATER FILLING PUMP	Ex21	Condensation water filling pump alarm	<ul style="list-style-type: none"> The cycle is suspended. If detected during configuration, the cycle start will not be permitted. 	<ul style="list-style-type: none"> Pump disconnected (wiring or connector error). Pump faulty. Water filling pump TRIAC error (short-circuit, diode mode, open circuit) (power board error).
		Ex22	Condensation water filling pump detection alarm	<ul style="list-style-type: none"> The cycle is suspended. If it is detected before the cycle starts, the cycle start will not be permitted. 	<ul style="list-style-type: none"> Pump TRIAC detection circuit error (main board error).
Ex30	CONDUCTIVITY SENSOR	Ex31	Conductivity Sensor Frequency too HIGH	No action.	<p>Only active during diagnostics of the HUMIDITY SENSOR SHORT-CIRCUIT.</p> <ul style="list-style-type: none"> The oscillation Frequency is out of Range (main board failure).
		Ex32	Conductivity Sensor Frequency too LOW	No action.	<p>Only active during diagnostics of the HUMIDITY SENSOR SHORT-CIRCUIT.</p> <ul style="list-style-type: none"> The drum is not short-circuited. Wiring error. The oscillation Frequency is out of Range (main board failure).
Ex40	DOOR	Ex45	Door Closed Sensing Alarm	<ul style="list-style-type: none"> The cycle is suspended. If it is detected before the cycle starts, the cycle start will not be permitted. 	<p>Error in the door closed detection circuit.</p> <ul style="list-style-type: none"> Door micro-switch faulty or disconnected. Main board error

FAMILY		ALARM CODE	Full name	Action	Notes and possible causes
E0x50	DRUM ROTATION MOTOR	Ex51	Motor power TRIAC short-circuited	<ul style="list-style-type: none"> ▪ The cycle is suspended. ▪ If it is detected before the cycle starts, the cycle start will not be permitted. 	<ul style="list-style-type: none"> ▪ Motor faulty. ▪ Faulty wiring. ▪ Main circuit board faulty.
		Ex52	Motor thermal cut-out triggered	<ul style="list-style-type: none"> ▪ The cycle is suspended. ▪ If it is detected before the cycle starts, the cycle start will not be permitted. 	<ul style="list-style-type: none"> ▪ Motor faulty. ▪ Motor thermal cut-out has triggered. ▪ Faulty wiring. ▪ Main circuit board faulty.
		Ex53	Motor TRIAC “sensing” circuit faulty	<ul style="list-style-type: none"> ▪ The cycle is suspended. ▪ If it is detected before the cycle starts, the cycle start will not be permitted. 	<ul style="list-style-type: none"> ▪ Main circuit board faulty.
		Ex54	Motor blocked	<ul style="list-style-type: none"> ▪ The cycle is suspended. ▪ If it is detected before the cycle starts, the cycle start will not be permitted. 	<ul style="list-style-type: none"> ▪ Washing load is too large. ▪ Power supply voltage low. ▪ Motor/drive system blocked.
		Ex55	Inverter board safety alarm	<ul style="list-style-type: none"> ▪ The cycle is suspended. ▪ If it is detected before the cycle starts, the cycle start will not be permitted. 	<p style="text-align: center;">-----</p>
		E57	Inverter is drawing too much current (>15 A)	<ul style="list-style-type: none"> ▪ The cycle is suspended. ▪ If it is detected before the cycle starts, the cycle start will not be permitted. 	<ul style="list-style-type: none"> ▪ Motor-inverter wiring faulty. ▪ Inverter board faulty. ▪ Motor faulty.
		E58	Inverter is drawing too much current (>4.5 A)	<ul style="list-style-type: none"> ▪ The cycle is suspended. ▪ If it is detected before the cycle starts, the cycle start will not be permitted. 	<ul style="list-style-type: none"> ▪ Abnormal motor operation (overload). ▪ Motor-inverter wiring faulty. ▪ Motor faulty. ▪ Inverter board faulty.
		E59	No signal from tachometric generator for 3 seconds	<ul style="list-style-type: none"> ▪ The cycle is suspended. ▪ If it is detected before the cycle starts, the cycle start will not be permitted. 	<ul style="list-style-type: none"> ▪ Motor-inverter wiring faulty. ▪ Inverter board faulty. ▪ Motor faulty.

FAMILY		ALARM CODE	Full name	Action	Notes and possible causes
E0x50	DRUM ROTATION MOTOR	E5A	Overheating on cooling dissipater for Inverter (>88°C)	<ul style="list-style-type: none"> ▪ The cycle is suspended. ▪ If it is detected before the cycle starts, the cycle start will not be permitted. 	<ul style="list-style-type: none"> ▪ Overheating caused by continuous operation or ambient conditions. ▪ Inverter board faulty. NTC open (on the Inverter board).
		E5H	Input voltage is lower than 175 V	<ul style="list-style-type: none"> ▪ The cycle is suspended. ▪ If it is detected before the cycle starts, the cycle start will not be permitted. 	<ul style="list-style-type: none"> ▪ Faulty wiring. ▪ Inverter board faulty.
		E5C	Input voltage is too high - greater than 430 V	<ul style="list-style-type: none"> ▪ The cycle is suspended. ▪ If it is detected before the cycle starts, the cycle start will not be permitted. 	<ul style="list-style-type: none"> ▪ Input voltage is too high (measure the grid voltage). ▪ Inverter board faulty.
		E5d	Data transfer error between Inverter and main PCB	<ul style="list-style-type: none"> ▪ The cycle is suspended. ▪ If it is detected before the cycle starts, the cycle start will not be permitted. 	<ul style="list-style-type: none"> ▪ Line interference. ▪ Faulty wiring. ▪ Main board or Inverter board faulty.
		E5E	Communication error between Inverter and main PCB	<ul style="list-style-type: none"> ▪ The cycle is suspended. ▪ If it is detected before the cycle starts, the cycle start will not be permitted. 	<ul style="list-style-type: none"> ▪ Faulty wiring between main board and Inverter. ▪ Inverter board faulty. ▪ Main board faulty.
		E5F	Inverter PCB fails to start the motor	<ul style="list-style-type: none"> ▪ The cycle is suspended. ▪ If it is detected before the cycle starts, the cycle start will not be permitted. 	<ul style="list-style-type: none"> ▪ Faulty wiring. ▪ Inverter board faulty. ▪ Main board faulty.


FAMILY		ALARM CODE	Full name	Action	Notes and possible causes
Ex60	HEATING ELEMENTS	Ex62	Compressor short-circuited	<ul style="list-style-type: none"> The drying cycle is suspended. If it is detected before the cycle starts, the cycle start will not be permitted. 	<ul style="list-style-type: none"> Compressor short-circuited. Compressor current leakage. Faulty wiring. Main circuit board faulty.
		Ex63	Compressor alarm	<ul style="list-style-type: none"> The drying cycle is suspended. If it is detected before the cycle starts, the cycle start will not be permitted. 	<ul style="list-style-type: none"> Compressor disconnected (wiring or connector error). Compressor thermal cut-out has triggered. Compressor faulty. Relay error (main board faulty).
		Ex64	Faulty compressor "sensing" circuit	<ul style="list-style-type: none"> The cycle is suspended. If it is detected before the cycle starts, the cycle start will not be permitted. 	<ul style="list-style-type: none"> Error in the compressor detection circuit. Main board faulty.
0x70	NTC	Ex71	Drying NTC alarm	<ul style="list-style-type: none"> The cycle is suspended. If it is detected before the cycle starts, the cycle start will not be permitted. 	<p>NTC1 reading out of range.</p> <ul style="list-style-type: none"> Wiring Failure. NTC Failure. NTC reading circuit error (main board error).
0x80	IU	Ex83	Incorrect selector dial position	<ul style="list-style-type: none"> No action. 	<ul style="list-style-type: none"> The code for the selector position is not recognised. Selector faulty (main board error).
		Ex86	Incorrect selector configuration	<ul style="list-style-type: none"> No action. 	<ul style="list-style-type: none"> Incorrect Selector Configuration (Main Board Failure). Selector faulty (main board error).
		Ex87	Self-diagnosis of main circuit board faulty	<ul style="list-style-type: none"> No action. 	<ul style="list-style-type: none"> Main board faulty.

FAMILY		ALARM CODE	Full name	Action	Notes and possible causes
Ex90	CFG	Ex91	User interface board communication alarm	<ul style="list-style-type: none"> ▪ No action possible. 	<ul style="list-style-type: none"> ▪ Faulty wiring. ▪ User interface board faulty. ▪ Main board faulty.
		Ex92	Inconsistent user interface board protocol	<ul style="list-style-type: none"> ▪ No action possible. 	<ul style="list-style-type: none"> ▪ The User Interface board is not compatible with the Main Board.
		Ex93	MCF checksum alarm	<ul style="list-style-type: none"> ▪ The machine could not work until a right configuration file is programmed. 	<ul style="list-style-type: none"> ▪ Wrong Machine Configuration File.
		Ex94	CCF checksum alarm	<ul style="list-style-type: none"> ▪ The machine could not work until a right configuration file is programmed. 	<ul style="list-style-type: none"> ▪ Wrong Cycle Configuration File.
		Ex97	Missing programme on CTF alarm	<ul style="list-style-type: none"> ▪ Only detected when configuration is performed. ▪ Does not allow the cycle to start. 	<ul style="list-style-type: none"> ▪ Wrong selector configuration (MCF) or missing cycle on cycle table (CCF).
		Ex98	Inconsistent inverter board protocol	<ul style="list-style-type: none"> ▪ Only detected when configuration is performed. ▪ Does not allow the cycle to start. 	<ul style="list-style-type: none"> ▪ The User Interface board is not compatible with the Main Board. ▪ Inverter board faulty. ▪ Bad main board configuration.
		Ex9C	User interface checksum alarm	<ul style="list-style-type: none"> ▪ No action possible. 	
		Ex9E	One or more touch keys on the user interface does not work	<ul style="list-style-type: none"> ▪ No action possible. 	<ul style="list-style-type: none"> ▪ Faulty wiring. ▪ Presence of damp on the user interface board. ▪ Board faulty.


FAMILY		ALARM CODE	Full name	Action	Notes and possible causes
ExB0 (ExH0)	POWER SUPPLY	ExH1	Power supply frequency out of range	<ul style="list-style-type: none"> If detected in setup, it would not be possible cycle starting. If happens during cycle execution, it suspend working. It is automatically cleared when power supply return within right limits, it would be possible to start. If a cycle was temporary suspended due to this alarm it automatically restarts. 	<ul style="list-style-type: none"> Power Supply Problems. Wrong MCF. Main board error.
		ExH2	Power supply voltage out of range (too HIGH)		<ul style="list-style-type: none"> Power Supply Problems - Too HIGH VOLTAGE. Wrong MCF. Main board error.
		ExH3	Power supply voltage out of range (too LOW)		<ul style="list-style-type: none"> Power Supply Problems - TOO LOW VOLTAGE. Wrong MCF. Main board error.
		ExH4	Zero Watt relay alarm	<ul style="list-style-type: none"> The tumble dryer is working properly but the zero Watt circuit is never activated. 	<ul style="list-style-type: none"> Main board faulty.
		ExHD	Current leakage alarm	<ul style="list-style-type: none"> The cycle is suspended. 	<ul style="list-style-type: none"> Current leakage of any actuator. Faulty wiring. Main board faulty.
		ExHE	Safety line alarm	<ul style="list-style-type: none"> The cycle is suspended. 	<ul style="list-style-type: none"> Main board faulty.
		ExHF	Safety line sensing alarm	<ul style="list-style-type: none"> The cycle is suspended. 	<ul style="list-style-type: none"> Main board faulty.
ALARMS		ExF6	Microprocessor safety reset	<ul style="list-style-type: none"> No action possible. 	<ul style="list-style-type: none"> Main board faulty.

10 Troubleshooting

10.1 The diagnostics programme cannot be accessed




10.2 The LEDs do not light up after the buttons are pressed



Important!

You cannot access the diagnostics system if the main circuit board has not been configured correctly: configuration errors E93 E94 are displayed by the flashing of all LEDs.

10.3 The drying cycle is long and the washing is still humid




10.4 Checking the heat pump performance

To check the correct functioning of the heat pump, position the sensors in the points indicated and compare the graphs with those provided below.


In the event of significant variations, the presence of a fault is likely.

10.4.1 Models without auxiliary condenser




- 1 Condenser inlet
- 2 Condenser outlet

- 3 Evaporator inlet
- 4 Evaporator outlet




10.4.2 Models with auxiliary condenser HP 2C



- 1 Condenser inlet
- 2 Condenser outlet

- 3 Evaporator inlet
- 4 Evaporator outlet



10.5 Servicing the heat pump circuit

10.5.1 Replace compressor



The circuit is evacuated with the compressor switched off.


Dispose of the R407c coolant complying with the legal provisions in your country.

- Disconnect the appliance from the power supply.
- If there is a loading and draining valve evacuate the gas by connecting the evacuation pipe directly to it.
- If there is no loading and draining valve evacuate the gas by inserting the specific pin valve (1).
- Evacuation should take 15 minutes and should only be performed on the suction side.
- During the evacuation cycle, the compressor will need to be shaken at least once to release as much gas as possible still combined with the oil.
- By doing so, as much gas and humidity as possible will be removed from the cooling circuit.




As R407c gas is not inflammable and there are no risks of explosion, it is possible to unsolder the copper pipes using a specific tool or a gas pipe.

- Unsolder the suction conduit and gas supply.
- Slacken the compressor from its slot and remove it.



If it is not already there, connect a valve to the loading pipe (2) to carry out the gas loading stage.

This can be welded directly onto the loading pipe previously cut or, make the connections using LOCKRING connections (3).



10.5.2 Filling

The coolant can be topped up directly from the bottle using purpose-provided scales (4).

R407a coolant is supplied in disposable bottles.


During filling, the compressors must be switched off and the serviceman must wear appropriate protection devices.

R407c 570g models without auxiliary condenser.

R407c 650g models with auxiliary condenser.



11 Door reversibility



Are the buttons unobstructed and do they activate

12 Revisions

Revision	Date	Description	Written by	Approved by - on
00	07/2012	Document creation	A.D.L.	
01	11/2013	Added EDR12 board	A.D.L.	