

SERVICE MANUAL COOKING

FOR INTERNAL AND PARTNERS USE ONLY

© ELECTROLUX HOME PRODUCTS Consumer Service - EMEA Quality & Continuous Improvement - Technical Support **OVEN User Interface**

VCU & VCU+





ΕN

Publication number 599 821 – 317 Edition: 12/2017 - Rev. 00

CONTENTS

<u>CC</u>	ONTENTS	1
<u>1</u>	PURPOSE OF THIS MANUAL	2
<u>2</u>	SAFETY	3
<u>3</u>	VCU (VISION COOKING UPDATE)	4
<u>4</u>	VCU DEMO MODE	7
<u>5</u>	VCU SERVICE MODE	11
<u>6</u>	VCU+ DEMO MODE	14
<u>7</u>	VCU+ SERVICE MODE	15
<u>8</u>	ACCESSING VCU & VCU+	16
<u>9</u>	ERROR CODES	17

1 PURPOSE OF THIS MANUAL

The purpose of this Service Manual is to provide Service Engineers who are already familiar with the repair procedures with information regarding: **Electro mechanical Ovens** with the User Interface Hexagon Touch. With reference to the Hexagon Button Service manual 599737823

Document Revisions

Rev.	Date	Description	Author
00	12/2017	Document creation	BSP

2 SAFETY



- All the work to be performed inside the appliance requires specific skills and knowledge and may only be carried out by qualified and authorised Service Engineers
- Before you access internal components, take the plug out of the socket to disconnect the power supply.
- Some of the components in the mechanical part could cause injuries, so wear suitable protection and proceed with caution.

3 VCU (VISION COOKING UPDATE)

3.1 VCU Display

VCU Front View	VCU Text Display	VCU PCB Configuration
	My Programmes Assisted Cooking Heating Functions	 Power board OVC3000 MACS-Sidekick Processor Buzzer

3.2 VCU Touch Electronics

Brand	Type of Electronics	Touch Board
U	Millenium 15 Smart Shuttle	
AE	Shuttle	
	Touch Horizontal	
trolux	Touch Smart	
(1) Elect	Touch Side	
	Millenium 15 Touch Horizontal	

3.3 VCU+ (Vision Cooking Update)

VCU+ Front View	VCU+ Text Display	VCU+ PCB Configuration
	My Programmes Assisted Cooking Heating Functions	 Power supply 5V DC SideKick Processor Buzzer

3.4 VCU+ Touch Electronics

Brand	Type of Electronics	Touch Board
AEG	Touch Horizontal	

4 VCU DEMO MODE



* Activate Demo Mode: The appliance is in Off-State

**All heating elements and the hot air ventilators are deactivated

***Deactivate Demo Mode: Use the same procedure to deactivate



Activate Demo Via Touch	User Interface	
Press the On/Off key (1) as long as the display shows the on-state again. Buzzer sounds. Press simultaneously the Menu (4) key and the Memory (5) key for approximately 2 seconds. On the display appears DEMO		
Activate Demo Via Menu	User Interface	
1. Switch on the appliance		VCU
2. Select "Basic Settings" and Press OK	Cleaning Basic Settings Specials	Shuttle
3. Select "Demo Mode" and Press OK	Cleaning Reminder DEMO DEMO DEMO Service	
4. Select "On" and Press Ok	DEMO Mode ^/~to adjust, OK to confirm OFF ON DEMO Mode – insert code ^/~to adjust, OK to confirm 2468	
 Insert the activation code → 2 : 4 : 6 : 8 Choose the number using the shuttle " + , - " and press OK 	DEMO My Programmes Assisted Cooking Heating Functions	





5 VCU SERVICE MODE

*To activate service mode: Disconnect the appliance once from the power supply

**Initial operation or new user interface (service call): The activation of service mode can only be done, while no language is set

*****Appliance in operating:** The activation of service mode can only be done, while the software appears

****During the service mode, it **isn't** necessary to use the food probe sensor to continue

***** **Deactivate service mode:** After the service mode process, disconnect the appliance from the power supply

******Fill up the Water tank for steam Ovens

Service mode	User Interface	
Switch on the appliance (1) Touch Simultaneously the Menu (4) key and the Baking (2) key for approximately 2 seconds. Buzzer sounds By turning the Shuttle up (8), the components and the heating elements are activated.		
By touching the OK (9) key, the next test phase will be active.	Shuttle Smort	



*To activate service mode: This test can only be activated as long as manufacturer logo is displayed.

**It is always important to control all test points, to continue and change to the new test phase.

***** Deactivate service mode: Once the display appears "Factory test done", disconnect the appliance from the power supply

Service mode	User Interface	
Switch on the appliance (1) Touch Simultaneously the Home (10) key and the Menu (4) key for approximately 2 seconds. Buzzer sounds By turning the Shuttle up (8), the functions are activated. By touching the OK (9) key, the next test phase will be active.		VCU Shuttle

6 VCU+ DEMO MODE

Activate Demo Via Menu	User Interface	
 Switch on the appliance Select "Basic Settings" and Press OK Cleaning Basic Settings Specials Select "Demo Mode" and Press OK 		
Cleaning Reminder DEMO DEMO Service	AEG AEG AEG AEG AEG AEG AEG AEG	VCU
4. Select "On" and Press Ok DEMO Mode ~/~to adjust, OK to confirm OFF ON	67	+ Touch
DEMO Mode – insert code ~/~to adjust, OK to confirm 2468		
5. Insert the activation code \rightarrow 2 : 4 : 6 : 8		
Choose the number using the touch " 6 , 7 " keys and press OK		

7 VCU+ SERVICE MODE

*To activate service mode: Disconnect the appliance once from the power supply

**Initial operation or new user interface (service call): The activation of service mode can only be done, while no language is set

*****Appliance in operating:** The activation of service mode can only be done, while the software appears

****During the service mode, it **isn't** necessary to use the food probe sensor to continue

***** **Deactivate service mode:** After the service mode process, disconnect the appliance from the power supply

******Fill up the Water tank for steam Ovens

Service mode	User Interface	
Switch on the appliance (1) Touch Simultaneously the Home (10) key and the Menu (4) key for approximately 2 seconds. Buzzer sounds By touching the Up key (7), the components and the heating elements are activated. By touching the OK (9) key, the next test phase will be active.		VCU Shuttle

8 ACCESSING VCU & VCU+



2. Unsnap the VCU Cover



Open the command panel and access the User Interface



- 3a. Remove the Rast connector from the PCB
- 3b. Unsnap the PCB from the plastic UI support

1.

9 ERROR CODES

Refer 599793313 for error codes