



Wire harness (door)
111 20 21-10

Wire harness (base)
111 11 47-20

Connections (door)
111 20 79-00; EH3.1
111 20 52-00; E02.4

Connections (base) (D)
111 20 31-00; KRGM
111 30 15-00; EM2.4
111 11 52-01; EMV.4
111 11 53-00; EM2.3
111 11 54-00; ETTS.4

VDR 111 207 810
© Electrolux