



- | | | | |
|----|---|---------|--------------------------------|
| b2 | Door switch | C1 | Start capacitor |
| b3 | Timer contact | AIF | AIF capacitor |
| b5 | Temp. selector | m1 | Timer motor |
| b7 | Floater switch | m2 | Main pump |
| b9 | Salt switch | m3 | Drain pump |
| f1 | Thermostat 65° C | R1 | Heater with protectors |
| f2 | Thermostat 55° C | S1 | Inlet valve |
| f3 | Overheating protector-
(boiling protector) | S3 | Regeneration valve |
| f5 | Pressure level switch | S4 | Rinse aid-coil |
| h2 | Lamp washing | ---●--- | Connection 6.6 mm on component |
| h4 | Lamp salt | —○— | Connection 6.3 mm on timer |
| Tb | Terminal block | ===== | Internal connection on timer |
| | | ----- | Connection with wire |

El. circuit diagram.

155 11 41