







Al.f = Anti-interference filter  
 b0.a,b = Line switch  
 b0.c = Prog. switch  
 b2 = Door switch  
 b7 = Floater switch  
 b9 = Salt switch

f3.2 = Overheating thermostat  
 f3.3 = Overheating protector  
 f5.1 = Level pressostat  
 H1 = Heater  
 K1 = Start capacitor  
 m2 = Main pump  
 m3 = Drain pump

Nt = Net terminal  
 Te = Thermistor NTC  
 S1 = Inlet valve  
 S2/4 = Detergent/Rinse aid coil  
 S3 = Regeneration valve

 = 6.3mm connection on component  
 = PCB -- -- component  
 = 6.3mm -- -- electronic  
 = PCB -- -- electronic  
 = Internal connection on electronic-or component  
 = Connection with wire