



- | | | | |
|------|---|---------|----------------------------------|
| b2 | Door switch | Tb | Terminal block |
| b3 | Timer contact | C1 | Start capacitor |
| b5.0 | Temp. selector 65°C | *) AIF | AIF capacitor, not in all models |
| b5.1 | Temp. selector 55°C | m1 | Timer motor |
| b5.2 | Temp. selector 45°C | m2 | Main pump |
| b7 | Floater switch | m3 | Drain pump |
| b9 | Salt switch | R1 | Heater with protectors |
| f1 | Thermostat 65°C | S1 | Inlet valve |
| f2 | Thermostat 55°C | S3 | Regeneration valve |
| f2.1 | Thermostat 45°C | S4 | Rinse aid-coil |
| f3 | Overheating protector-
(boiling protector) | ---●--- | Connection 6.6 mm on component |
| f5 | Pressure level switch | ---○--- | Connection 6.3 mm on timer |
| h2 | Lamp washing | ==== | Internal connection on timer |
| h4 | Lamp salt | ----- | Connection with wire |

El. circuit diagram. Level 10
With softener, temp. switch 45/55/65°C

155 1247 REV A