



Bratofenschalter		1	2	3	4	5	6	7	8	9	10	11
CIRCULATED		1a	2a	3a	4a	5a	6a	7a	8a	9a	10a	11a
0	0											
1	36								X	X		
2	72					X			X	X		
3	108					X	X		X	X		
4	144					X	X	X	X	X		
5	180					X	X	X	X	X	X	
6	216					X	X	X	X	X	X	X
7	252					X	X	X	X	X	X	X
8	288					X	X	X	X	X	X	X
9	324					X	X	X	X	X	X	X