



Bratofenschalter	CIRCULED IIII										
	1a	2a	3a	4a	5a	6a	7a	8a	9a	10a	11a
0											
1	LA							X	X	X	
2	HOT AIR	X	X		X		X	X	X	X	X
3	T/B	X	X				X	X	X	X	X
4	BOTTOM	X					X	X	X	X	X
5	DEFROST				X			X	X	X	
6	GRILL 1		X				X	X	X	X	X
7	GRILL 2	X	X				X	X	X	X	X
8	INFRA	X	X				X	X	X	X	X

N0330210600