



Bratofenschalter		1	2	3	4	5	6	7	8	9	10	11
HOT AIR 4.1		1a	2a	3a	4a	5a	6a	7a	8a	9a	10a	11a
0	0											
1	LA							X	X		X	
2	MULTI			X	X	X	X	X	X		X	X
3	PIZZA	X		X	X	X	X	X	X		X	X
4	TURBO		X		X	X	X	X	X		X	X
5	61/TURN		X				X	X	X	X	X	X
6	62/TURN	X	X				X	X	X	X	X	X
7	TOP	X					X	X	X		X	X
8	BOTTOM		X				X	X	X		X	X
9	T/B	X	X				X	X	X		X	X

N0330330700