



| Brotfenschalter | | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 |
|-----------------|---------|----|----|----|----|----|----|----|----|----|-----|-----|
| HOT AIR 4.1 | | 1a | 2a | 3a | 4a | 5a | 6a | 7a | 8a | 9a | 10a | 11a |
| 0 | 0 | | | | | | | | | | | |
| 1 | LA | | | | | | | X | X | | | X |
| 2 | MULTI | | | X | X | X | X | X | X | | X | X |
| 3 | PIZZA | X | | X | X | X | X | X | X | | X | X |
| 4 | TURBO | | X | | X | X | X | X | X | | X | X |
| 5 | B1/Turn | | X | | | | X | X | X | X | X | X |
| 6 | B2/TURN | X | X | | | | X | X | X | X | X | X |
| 7 | TOP | X | | | | | X | X | X | | X | X |
| 8 | BOTTOM | | X | | | | X | X | X | | X | X |
| 9 | T/B | X | X | | | | X | X | X | | X | X |

N0330340200