



Bratofensschalter	1	2	3	4	5	6	7	8	9	10	11
HOT AIR 4.1	1a	2a	3a	4a	5a	6a	7a	8a	9a	10a	11a
0	0	0									
1	LA						X	X		X	
2	MULTI			X	X	X	X	X	X	X	X
3	PIZZA	X		X	X	X	X	X	X	X	X
4	TURBO		X		X	X	X	X	X	X	X
5	B1/TURN		X			X	X	X	X	X	X
6	B2/TURN	X		X			X	X	X	X	X
7	TOP	X					X	X	X	X	X
8	BOTTOM		X				X	X	X	X	X
9	T/B	X	X				X	X	X	X	X

N0330413600