


This drawing contains confidential information and is the property of Electrolux, without whose permission it is not to be reproduced, stored in a retrieval system or otherwise used and it is to be returned promptly upon request to the design owner, who is responsible for the drawing.

Items shown in this drawing must not contain substances that are banned according to Directive 2002/95/EC, the RoHS Directive (Lead, Cadmium, Mercury, Hexavalent Chromium, Polychlorinated Biphenyls (PCB), or substances classified as "banned" or "Restricted" according to the Electrolux Restricted Materials List.



- ① = s13 / microswitch grill socket
- ② = s12 / microswitch grill > fryer
- ④ = f21 / saftey temperature limiter grill
- ⑥ = s21 / sensor grill
- ⑧ = r21 / heater grill

PE/Wanne PE/Blechträger

387 5319 00					
VARIANT NUMBER.	REPLACED NUMBER	POS.	MODEL	DESIGN USERS	CHANGES FROM THE BASE NUMBER

A		first edition		Weiß		DGT50061		19.04.2007							
POS				MODIFICATIONS				SIGNATURE		REQUEST		DATE			
MATERIAL						MODEL		SCALE				EUROPEAN METHOD			
TREATMENT						DESIGN USERS		REPLACES No							
DESIGN OWNER						DRN		CHD		Weiß		2D ONLY			
DGT						DATE		19.04.2007		APPR		Weiß			
												CONCEPT 3D			
												EXACT 3D			
												SUPPLY SPECIFICATIONS No			
TITLE										circuit diagram grill					
										Schaltplan Grill					
NUMBER										387 5319		REV		A	
												SHEET		1/1	

