



Items shown in this drawing must not contain substances that are banned according to Directive, 2002/95/EC, the RoHS Directive (Lead, Cadmium, Mercury, hexavalent Chromium, PBB and PBDE), or substances classified as "banned" or "Restricted" according to the Electrolux Restricted Materials List.
 This drawing contains confidential information and is the property of Electrolux. Without whose permission it may not be copied, shown or handed to a third party or otherwise used and it is to be returned promptly upon request to the design owner, who is responsible for the drawing.



- ① = s13 / microswitch grill socket
- ② = s12 / microswitch grill > fryer
- ③ = s14 / microswitch sensor
- ④ = f21 / safety temperature limiter grill
- ⑤ = f22 / safety temperature limiter fryer
- ⑥ = s21 / sensor grill
- ⑦ = s22 / sensor fryer
- ⑧ = r21 / heater grill
- ⑨ = r22 / heater fryer



387 5322 00					
VARIANT NUMBER.	REPLACED NUMBER	POS.	MODEL	DESIGN USERS	CHANGES FROM THE BASE NUMBER

A	first edition	WeiB	DGT50061	19.04.2007
POS	MODIFICATIONS		SIGNATURE	REQUEST
MATERIAL	MODEL		SCALE	EUROPEAN METHOD
TREATMENT	DESIGN USERS		REPLACES NO	
DESIGN OWNER	DRN	CHD WeiB	DERIVED FROM NO	
DGT	DATE 19.04.2007	APPR WeiB	SUPPLY SPECIFICATIONS NO	
TITLE circuit diagram grill-fryer				
Schaltplan Grill-Friteuse				
NUMBER 387 5322			REV A	A
			SHEET	1/1



GENERAL TOLERANCES
 ANGLES
 LENGTHS AND DIAMETERS