



- (E) Earth cabinet
- (I) Lamp switch (reflector flap)
- (L) Halogen lamp
- (M) alt.: Standard 230V lamp
- (K) Compressor
- (F) Flexible cord

| | | | |
|---|----------|----|--|
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| A | TM 04534 | SB | |

208 47 31-00
Variant No.

| | | | | | |
|---------------------------|--|------------------|------------------|----------------------------|---|
| DESIGN OWNER MA | | DRN SB | CHD APPR. | DATE 04-09-17 | TITLE Wiring diagram Kopplingschema |
| Electrolux | | | | NUMBER 208 47 31 | Rev. A |