



This drawing contains confidential information and is the property of Electrolux, without whose permission it may not be copied, shown or handed to a third party or otherwise used and it is to be returned promptly upon request to the design owner, who is responsible for the drawing.

Items shown in this drawing must not contain substances that are banned according to Directive, 2002/95/EC, the RoHS Directive (Lead, Cadmium, Mercury, hexavalent Chromium, PBB and PBBI), or substances classified as "Banned" or "Restricted" according to the Electrolux Restricted Materials List.

GENERAL TOLERANCES
ANGLES
LENGTHS AND DIAMETERS



COMPONENT LIST

POS	DESCRIPTION	QTY
1	HEATER/ZONE 210 230V	1
2	HEATER/ZONE 140/180 230V/210V	2
3	HEATER/ZONE 140 230V	2
4	HEATER/ZONE 140 230V	2
5	HEATER/ZONE 140 230V	2
6	HEATER/ZONE 140 230V	2
7	HEATER/ZONE 140 230V	2
8	HEATER/ZONE 140 230V	2

HC60:6 HC70:6 SIR

FRONT SEEN FROM BUTTOM 230V

ID	DESCRIPTION	ELUX PART NO.
1	Hob wiring cbl.	349 5112-04
2	INSULATION HOUSING	330 4175
3	LIST OF COMP CONTACTS	330 1786
4	COMPONENT LHS	330 2222

349 5391-01	027-610 NUMBER	POS	MODEL	DESCRIPTION	QUANTITY FROM THE ASSEMBLY

Electrolux

349 5391

Wiring hob assembly

Change design E-reg

DATE: 2007-02-02

SCALE: 1:1

REVISION: 1

DATE: 2007-02-02