



This drawing contains confidential information and is the property of Electrolux, without whose permission it shall not be reproduced, stored in a retrieval system or otherwise used and it is to be returned immediately upon request to the design owner, who is responsible for the drawing.

Items shown in this drawing must not contain substances that are banned according to Directive 2002/95/EC, the RoHS Directive. The Commission Report, Annexes and the RoHS website are hereby referred to for information. Components must be RoHS compliant, unless otherwise indicated. "Banned" or "Restricted" according to the Electrolux Restricted Materials List.



ID	Description	Elux part No.
10	Wiring power relay	349 4981-01
21	Wiring MO oven harness	349 5842-04
23	Wiring TO oven harness	349 5088-04
	List of crimp contacts	330 1766
	Component list	330 2222
	Insulation house	330 4175

Pos	No	Components
29	1	Thermostat top oven
28	1	Power board quick start
27	1	Capacitor
26	3	
25		Top oven selector
24		
23	1	Main terminal
22	1	Oven lamp near
21	1	Oven lamp side
20	1	Control lamp
19	1	Hot air motor
18		Cooling fan
17		Wiring power relay
16	1	Power relay top oven
15	2	Thermostat safety
14	1	Thermostat cooling fan
13	2	Wiring cooling fan
12	1	Heating element ring
11	1	Heating element top
10	1	Heating element bottom
9		

400V

B Correction wiring to lamp-capacitor		IAN	ABS6566	2008-01-29
POS	MODIFICATIONS	SIGNATURE	REQUEST	DATE
MATERIAL	WEIGHT	DESIGN USERS	REPLACES	EUROPEAN METHOD
TREATMENT	DERIVED FROM	SUPPLY SPECIFICATIONS		
DESIGN OWNER	DATE 2007-12-04	APR S.A.H	TITLE	Wiring oven assembly
Electrolux		NUMBER	349 5841	RIV B
349 5841-02		SHEET		