



7 OVEN SWITCH

∠ (ANGLE)	0	30	60-270	270	300	330
POSITION	0					
P ₃₀ - - - 05						
P - - - 02						
P - - - 01						
P - - - 03						
P - - - 04						