



7 OVEN SWITCH

∠ (ANGLE)	0	30	60-240	270	300
POSITION	0				
P <sub>30</sub> --- 05					
P --- 02					
P --- 01					
P --- 03					
P <sub>20</sub> --- 04					