



7 OVEN SWITCH

∠ (ANGLE)	0	30	60-240	270	300	330
POSITION	0					
P ₃ o - - - o5						
P o - - - o2						
P o - - - o1						
P o - - - o3						
P ₂ o - - - o4						