



8 OVEN SWITCH

∠ (ANGLE)	0	30	60-240	270	300	330
POSITION	0					
R 0 - - - 05						
P 0 - - - 01						
R 0 - - - 04						

7 HOB SWITCH

POS.	0	6	5	4	3	2	1
4 - P2							
3 - P2							
3 - P1							
1 - P1							
2 - P1							
5 - P3							

