



XX-YY
 XX-WIRE COLOR
 YY-WIRE GAUGE

B: BLACK
 C: BROWN

CY: BROWN/YELLOW
 CW: BROWN/WHITE
 G: GREEN
 GY: GREEN/YELLOW
 N: DARK BLUE

R: RED
 O: ORANGE
 OB: ORANGE/BLACK
 P: PINK
 S: GRAY

V: PURPLE
 W: WHITE
 Y: YELLOW
 TN: TANGERINE
 A: AQUA

Electric Dryer 220V Single Phase

EOC NOTE:
 EOC SIGNAL WILL SOUND WHEN TIMER IS IN COOL DOWN PERIOD OF CYCLE AND DURING EXTRA CARE CYCLE. IT OPERATES WITH SIGNAL ON 5 SECONDS AND OFF 70 SECONDS.

TO TEST: SET TIMER NEAR END OF CYCLE OR IN EXTRA CARE CYCLE AND WAIT 2 MINUTES FOR SIGNAL TO SOUND. TIMER MUST BE ALLOWED TO RUN, AND ELECTRICALLY ENERGIZE SIGNAL.