



WIRING

OVEN SWITCH	POSITIONI						Q	R	S	T	U
	0	1	2	3	4	5					
1 - 1a											
2 - 2a											
3 - 3a											
4 - 4a											
5 - 5a											
6 - 6a											

357 543101a