



OVEN SWITCH	8	72	144	216	288
4 - P2	0				
3 - P1					
1 - P1					
2 - P1					
5 - P3					

357 544802a