



OVEN SWITCH 9

0	72	144	216	288
7 - 7a				
6 - 5a				
5 - 5a				
4 - 5a				
3 - 3a				
2 - 2a				
1 - 1a				

ENERGY REGULATOR ②

POSITION	0	1	7	MULT.
S ₀ - - - 05				
P ₀ - - - 04				
R ₀ - - - 01				

WIRING

357 546401a