



WIRING DIAGRAM

OVEN SWITCH	0	60	120	180	240	300
4 - P2						
3 - P1						
1 - P1						
2 - P1						
5 - P3						

SWITCH	
POS.	0 35-318
P1-1	
P2-2	

357 586601a