





OVEN SWITCH	q	0	72	144	216	288
7 - 7a						
6 - 5a						
5 - 5a						
4 - 5a						
3 - 3a						
2 - 2a						
1 - 1a						



WIRING

357 549401a