



357 752103a

L1-1	L1-1
L2-2	L2-2
L3-3	L3-3
N-4	N-4
PE-5	PE-5
400V 3N-230V	400V 3N-230V

① OVEN SWITCH

0	72	144	216	288
4 - P2				
3 - P1				
1 - P1				
2 - P1				
5 - P3				

PLATE SWITCH ②

POSITION	0	6	5	4	3	2	1
P <sub>3</sub> 0-5	P3-5						
P <sub>1</sub> 0-2	P1-2						
P <sub>1</sub> 0-1	P1-1						
P <sub>2</sub> 0-3	P2-3						
P <sub>2</sub> 0-4	P2-4						

② COMM. PIASTRE

4A	4	4A	EQUIVALE A P2
3	3	2A	EQUIVALE A P1
2	2	5A	EQUIVALE A P3
1	1		
5	5		

① COMM. FORNO DREFFS

4A	4	4A
3	3	2A
2	2	5A
1	1	
5	5	