



OVEN SWITCH ②

0	60	120	180	240	300
4 - P2					
3 - P1					
1 - P1					
2 - P1					
5 - P3					

OVEN SWITCH ①

0	36	72	108	144	180	216	252	288	324
4 - P2									
3 - P2									
1 - P1									
2 - P1									
5 - P3									
4 - P2									
1 - P1									
2 - P1									
5 - P3									
1 - P1									
2 - P1									
5 - P3									



TRADITIONAL OVEN WIRING

MULTIFUNCTION OVEN

357 511212a