





OVEN SWITCH	72	144	216	288	VV
7 - 7a					
6 - 6a					
5 - 4a					
4 - 4a					
3 - 4a					
2 - 2a					
1 - 1a					



357 752703a