


① OVEN SWITCH

	8				
	0	72	144	216	288
4 - P2					
3 - P1					
1 - P1					
2 - P1					
5 - P3					

COMM. FORNO DREEFS 7



357 534703a