



OVEN SWITCH ①	②	③	④	⑤	⑥	⑦	
POS.	0	30	60+	240	270	300	330
4-P2							
3-P1							
1-P1							
2-P1							
5-P3							

WIRING

357 534905a