




OVEN SWITCH						
0	60	120	180	240	300	
4 - P2						
3 - P1						
1 - P1						
2 - P1						
5 - P3						

SWITCH		35-318
POS.	0	
P1-1		
P2-2		



WIRING

357 753602a