



SCHEMA ELETTRICO

OVEN SWITCH

	0	60	120	180	240	300
$\nabla$						
4 - P2						
3 - P1						
1 - P1						
2 - P1						
5 - P3						

357 662301a