



WIRING DIAGRAM

OVEN SWITCH	ANGOLAZIONE \angle°	40	80	120	160	200	240	280	320
POSIZIONI	0	1	2	3	4	5	6	7	8
	7 - 7a								
	6 - 6a								
	5 - 5a								
	4 - 4a								
	3 - 3a								
	2 - 2a								
	1 - 1a								

357 586703a