





OVEN SWITCH

ANGLE	0	30	60-240	270	300
POSITION	0	LAMP	OVEN	BOTTOM	TOP
P <sub>2</sub>	5				
P <sub>1</sub>	2				
P <sub>3</sub>	1				
	3				
	4				



WIRING