




COLLEGAMENTI ELETTRICI



OVEN SWITCH

FUNCTIONS	Icons	0	1	2	3	4	5
POSITIONS		0	1	2	3	4	5
		0	60	120	180	240	300
6 - P6							
5 - P5							
4 - P4							
3 - P3							
2 - P2							
1 - P1							



WIRING