




OVEN SWITCH

ANGLE	0	30	60-240	270	300
POSITION	0	LAMP	OVEN	BOTTOM	TOP
P <sub>2</sub>	5				
P <sub>1</sub>	2	1			
P <sub>2</sub>	4				



WIRING

357 755001a