


SCHEMA ELETTRICO



① OVEN SWITCH

④	0	8	W	W	⊕
4 - P2	72	144	216	288	
3 - P1					
1 - P1					
2 - P1					
5 - P3					

357 637901a