



OVEN SWITCH

ANGLE	0	30	60-240	270	300
POSITION	0	LAMP	OVEN	BOTTOM	TOP
	P <sub>2</sub> → 5				
	P <sub>1</sub> → 2				
	P <sub>2</sub> → 4				



WIRING

