



OVEN SWITCH	72	144	216	288
4 - P2	0	72	144	216
3 - P1				
1 - P1				
2 - P1				
5 - P3				

357 630402a