



OVEN SWITCH

ANGOLAZIONE \angle°	40	80	120	160	200	240	280	320
POSIZIONI	1	2	3	4	5	6	7	8
7 - 7a								
6 - 6a								
5 - 5a								
4 - 4a								
3 - 3a								
2 - 2a								
1 - 1a								

357 632604a