


SCHEMA ELETTRICO



OVEN SWITCH

| OVEN | 9 | | | | | | |
|------|---|----|----|-----|-----|-----|-----|
| POS. | 0 | 30 | 60 | 240 | 270 | 300 | 330 |
| 4-P2 | | | | | | | |
| 3-P1 | | | | | | | |
| 1-P1 | | | | | | | |
| 2-P1 | | | | | | | |
| 5-P3 | | | | | | | |