


OVEN SWITCH	0	30	60-240	270	300
4 - P2					
3 - P1					
1 - P1					
2 - P1					
5 - P3					



POSITION	0	1	2	3	4	7 max.
S	●	●	●	●	●	●
P	●	●	●	●	●	●
F	●	●	●	●	●	●

ENERGY REGULATOR ①②③④

