




**OVEN SWITCH**

	8				
4 - P2	0	72	144	216	288
3 - P1					
1 - P1					
2 - P1					
5 - P3					



**357 767701a**