

PLATE SWITCH

| POS | 0 | 6 | 5 | 4 | 3 | 2 | 1 |
|--------|---|---|---|---|---|---|---|
| 4 - P2 | | ■ | ■ | ■ | ■ | ■ | ■ |
| 3 - P2 | | | | ■ | ■ | ■ | ■ |
| 3 - P1 | | | | | | ■ | ■ |
| 1 - P1 | | ■ | ■ | ■ | ■ | ■ | ■ |
| 2 - P1 | | | | | | ■ | ■ |
| 5 - P3 | | | | | | | ■ |

