



OVEN SWITCH

	0	8	Y	Δ	W
4 - P2		72	144	216	288
3 - P1					
1 - P1					
2 - P1					
5 - P3					

357 411001a