



OVEN SWITCH ①

OVEN		⌀	▬	▬	▬	▬
POS.	0	30	60 ± 240	270	300	330
4-P2						
3-P1						
1-P1						
2-P1						
5-P3						

