


SCHEMA ELETTRICO



OVEN SWITCH	B	Y	⊕
0	72	144	216 288
4 - P2			
3 - P1			
1 - P1			
2 - P1			
5 - P3			

357 667903a