



OVEN SWITCH

ANGOLAZIONE	40	80	120	160	200	240	280	320	
POSIZIONI	0	1	2	3	4	5	6	7	8
7 - 7α									
6 - 6α									
5 - 5α									
4 - 4α									
3 - 3α									
2 - 2α									
1 - 1α									

357 692304a