



OVEN SWITCH	0	72	144	216	288
7 - 7α					
6 - 6α					
5 - 4α					
4 - 4α					
3 - 4α					
2 - 2α					
1 - 1α					

ENERGY REGULATOR ② ③ ④	
POSITION	0 1 7 max.
S	→ S
P2	→ 4
P1	→ 1

DOUBLE ENERGY REGULATOR ①	
POSITION	0 1 12
S	→ S
P2	→ 4
P1	→ 2
4	→ 4A

